

The Complete 6Volt to 12Volt Conversion guide for all Aircooled VW Vehicles

Guide | 15 Oct 2019 | Limebug Guide

The Complete 6Volt to 12Volt Conversion guide for all Aircooled VW Vehicles

How to do the complete conversion the right way, the things you can get away with and the things you really can't.

Parts list below of everything needed for a complete conversion:

1x Alternator conversion Kit 1x 12v Horn 1x 12v Coil 1x Carb Spacer (upto 31 PICT Carb) 2x 12v – 6v Fixed Voltage dropper 1x 12v fuel sender 1x 6 – 12volt Starter motor (with bush) 1x wiper motor armouridge 1x 12Volt Fuel Cutoff Plug 1x 12Volt Autochoke Coil 1x Indicator Relay 1x Headlight Relay 2x Headlight Bulbs 4x Indicator Bulbs 6x Dashboard Bulbs 2x Tail Light Bulbs 2x Sidelight Bulbs 1x Number Plate Light

(Optional for nostalgic look you can use external mounted voltage regulator and dynamo look alternator)