

Second Compressor Harness Loom Installation Guide Diagram for Manual Air Ride Management Systems

Guide | 17 Jun 2026 | Limebug Guide

Manual Air Ride Management System Second Compressor Loom Installation Guide Diagram

Please see diagram for installing the Second Compressor Loom to either a 2 Way or 4 Way Manual Air Ride Management System:

Need the loom?

If you require a second compressor loom for your 2 Way or 4 Way Manual Air Ride system, you can purchase these here:

- Edit Second Air Compressor / Management Wiring Harness, Suitable for ALP4, 3P, 3H, V2 &QUICKVIEW Air Management Systems Second Air Compressor / Management Wiring Harness, Suitable for ALP4, 3P, 3H, V2 & In StockSKU: 030010103£64.89inc 20% VAT Add to basket Quick view

Second Air Compressor / Management Wiring Harness, Suitable for ALP4, 3P, 3H, V2 &

In StockSKU: 030010103£64.89inc 20% VAT Add to basket Quick view

Need a management system?

Check out our options available here:

- Edit 4 Way Manual Air Ride Management System, 1/4", 4 Valve QUICKVIEW Air Management Systems 4 Way Manual Air Ride Management System, 1/4", 4 Valve BackorderSKU: 030010038OE Code: 27666From £293.99 Select options Quick view

4 Way Manual Air Ride Management System, 1/4", 4 Valve

BackorderSKU: 030010038OE Code: 27666From £293.99 Select options Quick view

- Edit 2 Way Manual Air Ride Management System, 1/4" QUICKVIEW Air Management Systems 2 Way Manual Air Ride Management System, 1/4" BackorderSKU: 030010323From £201.51 Select options Quick view

2 Way Manual Air Ride Management System, 1/4"

BackorderSKU: 030010323From £201.51 Select options Quick view

Have an Airlift 3P / 3H or ALP4 Management?

If you do, the second compressor harness will need wiring up slightly different. For this guide, please [click here](#)

LIMEBUG