

Manual Air Ride Management Kit Wiring / Valve / Pneumatic Diagrams

Guide | 10 Mar 2021 | Limebug Guide

Air Ride Manual 4-Valve Management System

Wiring Diagram for most Manual Operated Air Ride Systems

These wiring diagrams cover all “C” Model Viar Compressors as Included with our Manual Air Ride Management Kits

Use the Following Diagram for Twin Compressor Setups

We recommend all items are installed by a qualified individual(s). We accept no responsibility for any issues/damage caused when installing these parts.

Pneumatic Diagram for most Manual Operated Air Ride Systems

Pneumatics layout shown below courtesy of Airlift. Note you can use any air spring / shock in each corner: